


# Defining Netgear 2200 Routers

1 פתח את הדפדפן שלך והקלד: Http://10.0.0.138 :



2 הכנס Admin כהוא את שם המשתמש וסימא, ולאחר מכן לחץ OK.



3 לך ל BASIC SETTINGS בחלון, encapsulations לבחור PPPoE.

כניסה עם שם המשתמש שלך, ולאחר מכן הוספת @Username הסימא שלך.

לאחר מכן לחץ על APPLY.

**NETGEAR SMARTWIZARD** router manager  
RangeMax Next Wireless-N Modem Router model DGND200

**Basic Settings**

Encapsulation: PPPoE (PPP over Ethernet)

Login: @ineto

Password: .....

Service Name (if Required):

Idle Timeout (in Minutes): 0

Internet IP Address

Get Dynamically From ISP

Use Static IP Address: 95 - 86 - 101 - 156

Domain Name Server (DNS) Address

Get Automatically From ISP

Use These DNS Servers

Primary DNS: 212 - 76 - 127 - 133

Secondary DNS: 213 - 151 - 32 - 70

NAT (Network Address Translation)

Enable  Disable  Bridge

Buttons: Apply, Cancel, Test

**Help**

The Basic Settings pages allow you to configure, upgrade, or update the status of your NETGEAR Cable/DSL Wireless Router.

Click on an item in the leftmost column. The current settings for that area appear in the center column.

Helpful information related to the selected Settings page appears in the rightmost column. If you are using Internet Explorer, you may click on the center column to jump directly to the related help section down until you reach it.

**Basic Settings Help**

Note: If you are setting up the router for the first time, this may work for you with no changes.

**Does Your Internet Connection Require A Login?**

Select this option based on the type of account you have. If you need to enter login information every time you connect, you have a PPPoE account with your ISP, select **Yes**. Otherwise, select **No**.

Note: If you have installed PPP software such as WinPoE or Enternet (from PacBell), then you have PPPoE. Selecting **Yes** and configuring your router, you will not need software on your PC to connect to the internet.

**Internet Service Provider**

Select the service provided by your ISP. "Other" (PPPoE) is common. "PTIP" is used in Austria and other European countries. "Bupond" is for Australia only.

4 הגדרות הנתב שלך תהיינה לטעון בתוך כדקה. לאחר מכן, למסך הבא יופיע:



עכשיו הנתב שלך הותקן בהצלחה במחשב שלך.