


Siemens SL2-141




1. לאחר כניסה אל הדפדפן הקלידו את הכתובת הבאה: [Http//10.0.0.138](http://10.0.0.138):

שם המשתמש Admin ובתבנית הסיסמא Admin




2. הקליקו על הלשונית Advanced בתפריט העליון.



3. כעת יש להקליק על האפשרות internet בתפריט השמאלי



4. הקליקו על סמל העיפרון בשורה הראשונה מימין.




5. במסך הבא הקליקו על "Next".



6. כעת הסירו את הסימון מהאופציה Enable QoS ולאחר מכן הקליקו על "Next"




7. בתבנית Username הקלידו את שם המשתמש שלכם ואחריו @099
בתבנית Password הקלידו את הסמא שלכם, לאחר מכן סמנו את האופציה Always on והקליקו על Next.



8. בחלון הבא הקליקו על Apply לשם אישור ההגדרות.



9. כעת הקליקו על Finish לסיום הגדרת הראוטר לשם איתחול עצמי ושמירת ההגדרות. לאחר פעולה זו יתחבר הראוטר באופן אוטומטי לאינטרנט.



SIEMENS Quick Start | Status | Advanced | Wireless | Management

Language: English

Local Network
 Internet
 Connections
 DNS Server
 IGMP Proxy
 NAT Type
 DSL
 IP Routing
 Virtual Server
 NAT ALG
 Firewall
 Quality of Service
 Port Mapping

Internet Connection Configuration
 Choose Add or Edit to configure Internet connection.
 Choose Finish to apply the changes and reboot the system.


PVC Name	VPI/VCI	Category	Protocol	NAT	QoS	WAN IP Address	MTU	Edit
pppoe_8_48_1 (?)	8/48	UBR	PPPoE LLC/SNAP	On	On	Auto assigned	1492	
br_8_35 VLAN ID 0	8/35	UBR	Bridge LLC/SNAP	=	Off	=		
br_8_36 VLAN ID 0	8/36	UBR	Bridge LLC/SNAP	=	Off	=		
br_8_37 VLAN ID 0	8/37	UBR	Bridge LLC/SNAP	=	Off	=		
br_8_38 VLAN ID 0	8/38	UBR	Bridge LLC/SNAP	=	Off	=		

The Internet connection is NOT active if PVC name is marked with (?). You need to click "Finish" to apply the changes and reboot the system for activating this PVC.

Add Finish

WARNING:
 Router's settings are changed. New settings are only valid after REBOOTING router.

10. בזמן איתחול הראוטר יופיע המסך הבא ולאחריו תסתיים ההגדרה.



SIEMENS Quick Start | Status | Advanced | Wireless | Management

Language: English

Local Network
 Internet
 Connections
 DNS Server
 IGMP Proxy
 NAT Type
 DSL
 IP Routing
 Virtual Server
 NAT ALG
 Firewall
 Quality of Service
 Port Mapping

Reboot DSL Router
 The DSL router has been configured and is rebooting.
 Close the DSL router configuration window and wait for 2 minutes before reopening your web browser. If necessary, reconfigure your PC's IP address to match your new configuration.

WARNING:
 Router's settings are changed. New settings are only valid after REBOOTING router.

כעת השם משתמש והסיסמה מוגדרים בראוטר .

11. תלחיק הגדרת רשת אלהוטית :



אחרי שנכנסתם לעמוד הבית של הראוטר, היכנסו לכרטיסייה "Wireless".
 מסומן בתמונה במסגרת אדומה.

Siemens ADSL SL2-141 - Mozilla Firefox

קובץ עריכה תצוגה היסטוריה סימנות בליים עזרה

Siemens ADSL SL2-141

http://10.0.0.138/

ICQ Search

Siemens

Quick Start | Status | Advanced | **Wireless** | Management

Language: English

Connect to Internet **IWFreeGilad - FxP**

Your DSL router is **connected** to Broadband and you can now surf the Internet.

Current Connection Status:

Online Time	9 hours 11 mins 22 secs
Data Transmitted	1285614032 bytes
Data Received	504447232 bytes

More details can be found in the [Status](#) menu.

Clicking "Disconnect" will close down your Broadband connection. This will affect all computers currently connected.



Primo Telecommunication

072-2467000 | support@099.net.i | www.099.net.il



אחרי שהגעתם לכרטיסיית האינטרנט האלחוטי, תלחצו בצד השמאלי על "Security" מסומן בתמונה במסגרת צהובה.

Siemens ADSL SL2-141 - Mozilla Firefox

http://10.0.0.138/

SIEMENS Quick Start | Status | Advanced | Wireless | Management

Language: English

Basic Settings
Security
Access Control
Repeater
Quality of Service

Firmware: 3.104i
ADSL2+ : A2p8021g.d20h
Wireless: 4.150.10.26

Wireless Basic Settings

099.net.il

This page allows you to configure basic features of your wireless network. You can enable or disable the wireless interface, hide the network from active scans, set the wireless network name (also known as SSID) and select the working channel.

Enable Wireless Network

Wireless Interface	Network Name (SSID)	Hide Network	User Isolation	Maximum Users	Enabled
Wireless main network	[Redacted]	<input type="checkbox"/>	Off	128	<input checked="" type="checkbox"/>
Wireless.2	[Redacted]	<input type="checkbox"/>	Off	128	<input type="checkbox"/>
Wireless.3	[Redacted]	<input type="checkbox"/>	Off	128	<input type="checkbox"/>
Wireless.4	[Redacted]	<input type="checkbox"/>	Off	128	<input type="checkbox"/>

Transmission Mode: 802.11b/g mixed mode



Primo Telecommunication

072-2467000 | support@099.net.il | www.099.net.il



הסיסמה הקיימת מוצגת בתיבה שמסומנת במסגרת אדומה.
את סוג האבטחה ניתן לבחור בשורת הגלילה שמסומנת במסגרת כחולה.

41 - Mozilla Firefox

קובץ עריכה תצוגה היסטוריה סימיות בלים עזרה

Siemens ADSL SL2-141

http://10.0.0.138/

נצפה תדיר | כותרות אחרונות

Quick Start | Status | Advanced | **Wireless** | Management

Language: English

Select Wireless Network: [Redacted]

Wireless Security: **WPA-PSK**

Data Encryption: TKIP

WPA Pre-Shared Key **099.net.il**

Enter the key to be between 8 and 63 ASCII characters, or 64 hexadecimal digits

Format:

- Hexadecimal digits
(0-9,A-F,and a-f are valid)
- ASCII characters
(any printable characters are valid except: & < > , \)

Pre-Shared Key: **abc770twa**

WPA Group Rekey Interval: 0 seconds

Wi-Fi Protected Setup (WPS): Add Wireless Client

You can allow those WPS enabled clients to connect to your router securely through the [Add Wireless Client](#) window.

הרשת האלחוטית מותקנת בהצלחה



Primo Telecommunication

072-2467000 | support@099.net.il | www.099.net.il